Product Overview

F-555 Phenolic Prepregs

Park's F-555 is a carbon-filled MIL-R-9299 phenolic resin optimized for coating Carbonized Rayon cloth. F-555 is used extensively in the manufacture of high temperature rocket nozzles, heat shields, and combustion chambers.

Key Features & Benefits

- Provides a combination of high-strength and ablative properties for demanding applications
- Low thermal expansion
- Good Tack and Drape properties

Product Forms

- Available on a wide variety of reinforcements, including C2, NARC, CYDA and Acordis ENKA
- Available as Broadgoods, Bias Tape and Chopped Molding Compound
- Solution coated fabrics up to 152 cm wide
- Compatible with Autoclave or Press Molding processes

Applications / Qualifications

- Rocket Nozzles
- Combustion Chambers
- Heat Shields
- Rocket Motor Throat Sections

For Information about Park's materials:

Newton, KS +1.316.283.6500 info@parkaerospace.com www.parkaerospace.com



Technical Datasheet

F-555 Phenolic Prepregs

Prepreg Physical Properties

Reinforcement	C2	ENKA	NARC / CYDSA **	Glass	12kTW	3K8HS T300
Fabric Area Weight (gsm)	330	280	270	610	670	370
Prepreg Resin Content (%)	31 – 37	31 – 37	31 – 37	28 – 34	39 – 45	32 -38
Resin Flow (163°C, 1034 kPa) (%)	5 – 20	5 – 20	5 – 25		$10 - 20^{1}$	10-25
Volatiles (163°C, 5 min) (%)	2 – 5	2 – 5	2 - 8	2-5	<4	2-8
Filler Content (%)	9 -15	9 – 15	8 -16		-	9-16

^{**} Typical Values for carbonized rayon fabric

Cured Laminate Physical Properties

Reinforcement	C2	ENKA	NARC / CYDSA **	C2	Glass	T300
Product Form	8HS	8HS	8HS	CMC	18oz. Woven Roving	3K8HS
Per Ply Thickness (mm)	0.48	0.38	0.41		0.51	0.43
Specific Gravity ASTM-D-792	1.37	1.47	1.45	1.47	2.08	1.48
Hardness (Barcol) ASTM-D-2583	75	75	75	81	68	
Specific Heat (J/g°C) ASTM-C-351	8.9	2.1	1.17			
CTE – with-ply 27 - 204°C (ppm/°C) ASTM-D-696	15.5	7.2	7.2	1	1	
CTE – x-ply 27 – 204°C (ppm/°C) ASTM-D-696		12.2	12.2	1	1	
Thermal Conductivity with-ply @ 149°C (J/s m °C) ASTM-C-177			1.59		-	
Thermal Conductivity x-ply @ 149°C (J/s m °C) ASTM-C-177		0.87	1.02			

^{**} Typical Values for carbonized rayon fabric

All test data provided are typical values and not intended to be specification values. For review of critical specification tolerances, please contact a Park representative directly. Park reserves the right to change these values based on a nature process of refining our testing equipment and techniques.



^{1 344} kPa

Technical Datasheet

F-555 Phenolic Prepregs

Laminate Mechanical Properties

Reinford	ement	C2	ENKA	NARC / CYDSA **	C2	Glass	T300
Product Form		8HS	8HS	8HS	CMC	18oz. Woven Roving	3K8HS
Tensile Strengtl 24°C ASTM-D-638	h, 0° (MPa) Dry	241	145	179	48	352	544
Tensile Modulus 24°C ASTM-D-638	s, 0° (GPa) Dry	15.9	17.2	16.5	17.2	29	53.7
Compressive St 24°C ASTM-D-695	trength (MPa) Dry	317	379	317	290	152	268
Compressive M 24°C ASTM-D-695	odulus (GPa) Dry	22.1	19.3	15.2	16.5	4.7	47.5
Flexural Strengt 24°C ASTM-D-790	th (MPa) Dry	448	269	228	138	32.4	
Flexural Modulu 24°C ASTM-D-790	u s (GPa) Dry	15.9	19.3	16.5	17.2	23.4	
Short Beam Sho 24°C ASTM-D-5379	ear (MPa) Dry	30.3	35.2		30.3		35.9

All test data provided are typical values and not intended to be specification values. For review of critical specification tolerances, please contact a Park representative directly. Park reserves the right to change these values based on a nature process of refining our testing equipment and techniques.



Processing Guidelines

F-555 Phenolic Prepregs

Prepreg Storage Life

Out Life: 30 days @ 24°C Shelf Life: 6 months @ 4°C <u>Note</u>: The following guidelines are provided to assist Park material users with general recommendations for successful processing. The recommendations are for general review purposes only and process adjustments may be required to achieve optimum results in your specific manufacturing environment.

Autoclave Cure Cycle

- Apply 610 mm Hg vacuum (minimum) for 1 hour before beginning heat cycle
- Raise temperature from RT to 93°C at 1 3°C/min
- Hold product at 93°C for 30 minutes
- Increase autoclave pressure to 690 kPa and vent vacuum at 103 138 kPa
- Raise product temperature to 177 ± 3°C at 1 3°C/min
- Hold product at cure temperature for 60 90 minutes
- Cool to 66°C at no more than 3°C/min prior to releasing autoclave pressure
- Post Cure:
 - Heat Oven at 1 5 °C /min to 177°C and hold 2 hours
 - Heat oven to 204°C and hold 4 hours

All test data provided are typical values and not intended to be specification values. For review of critical specification tolerances, please contact a company representative directly.

Park Aerospace Corp. reserves the right to make changes without notice to any products described herein. Park does not assume any liability arising out of the application or use of any product described herein; and it does not grant any license under its patent or other rights or any such rights of others. Park also disclaims all warranties whether expressed, implied or statutory, including implied warranties of merchantability or fitness for a particular purpose.

Aeroglide®, ALPHA STRUT™, CoreFix®, Easycure E-710®, Electroglide®, Electrovue™, Peelcote™, Powerbond™, RadarWave™, SIGMA STRUT™ and Tin City Aircraft Works™ are trademarks or servicemarks of Park Aerospace Corp.

